

CARING & CLEANING OF YOUR INTEGRATED BIOMETRICS LES FINGERPRINT SCANNER

BEST PRACTICES

Cleaning the IB LES scanner is a simple process.

- Use a water-moistened rag to remove dirt and debris.
- Mild soap or detergent may be used for stubborn dirt and grime.
- Wipe clean using a dry cloth.

WARNINGS AND CONSIDERATIONS



- Alcohol and alcohol-based cleaning solutions may stain if allowed to remain on the platen.
- Wipe alcohol products from LES platen and clean using a water-based solution.
- Care should be taken to clean and remove chemicals immediately following a spill.
- Remove chemical solutions immediately using a water-moistened rag.
- Common chemicals that require immediate attention include:
 - Acetone and polish removers
 - Paint
 - Paint thinners
 - Stain removers
 - Gasoline or petroleum products
 - Pesticides and herbicides
 - DEET or DEET infused products
 - Cleaning cloths, rags, or devices impregnated with any of the above examples